
SEGMENT
* CODE_TYPE
* CODE_SOURCE
o VAL_TRUE_TRACK
o VAL_MAG_TRACK
o VAL_REVERS_TRUE_TRACK
o VAL_REVERS_MAG_TRACK
o VAL_LEN
o UOM_DIST
o TXT_RMK
ending at
starting at
TFC_FLOW_RESTR
* CODE_ID
* CODE_TYPE
o TXT_OPR_GOAL
o TXT_DESCR
o TXT_REMARK
TFC_FLOW_RTE
* NO_SEQ
part of
regulating the use
made of
composing
TFC_FLOW_RTE_ELEMENT
o VAL_SPEED
o UOM_SPEED
o CODE_SPEED_REF
o CODE_SPEED_CRITERIA
* NO_SEQ
RTE_PORTION
starting at
the beginning of
ending at
the end of
SIGNIFICANT_POINT
the beginning of
the end of
AD_HP
* CODE_ID
* TXT_NAME
o CODE_ICAO
o CODE_IATA
* CODE_TYPE
o [CODE_TYPE_MIL_OPS]
o [CODE_NATIONAL_TFC]
o [CODE_INTL_TFC]
o [CODE_SKED]
o [CODE_NON-SKED]
o [CODE_PRIV]
o [CODE_VFR]
o [CODE_IFR]
o TXT_DESCR_REF_PT
* GEO_LAT
* GEO_LONG
o CODE_DATUM
o VAL_GEO_ACCURACY
o UOM_GEO_ACCURACY
o VAL_ELEV
o VAL_ELEV_ACCURACY
o VAL_GEOID_UNDULATION
o UOM_DIST_VER
o VAL_CRC
o TXT_VER_DATUM
o TXT_NAME_CITY_SER
o TXT_DESCR_SITE
o VAL_MAG_VAR
o DATE_MAG_VAR
o VAL_MAG_VAR_CHG
o VAL_REF_T
o UOM_REF_T
o TXT_NAME_ADMIN
o TXT_DESCR_ACL
o TXT_DESCR_SRY_PWR
o TXT_DESCR_WDI
o TXT_DESCR_LDI
o VAL_TRANSITION_ALT
o UOM_TRANSITION_ALT
o TXT_RMK
based on
used as
based on
based on
used as
based on
is the end of
is the start of
used as
SID
* TXT_DESIG
o CODE_CAT_ACFT
o CODE_RNP
o TXT_DESCR_COM_FAIL
o CODE_TRANS_ID
* CODE_TYPE_RTE
o TXT_DESCR
o TXT_RMK
for
having
based on
used as
STAR
* TXT_DESIG
o CODE_CAT_ACFT
o CODE_TRANS_ID
o CODE_RNP
o TXT_DESCR_COM_FAIL
* CODE_TYPE_RTE
o TXT_DESCR
o TXT_RMK
for
having
based on
used as
based on
used as
AIRSPACE
* CODE_TYPE
* CODE_ID
o TXT_LOCAL_TYPE
o TXT_NAME
o CODE_CLASS
o CODE_LOC_IND
o CODE_ACTIVITY
o CODE_MIL
o CODE_DIST_VER_UPPER
o VAL_DIST_VER_UPPER
o UOM_DIST_VER_UPPER
o CODE_DIST_VER_LOWER
o VAL_DIST_VER_LOWER
o UOM_DIST_VER_LOWER
o CODE_DIST_VER_MAX
o VAL_DIST_VER_MAX
o UOM_DIST_VER_MAX
o CODE_DIST_VER_MNM
o VAL_DIST_VER_MNM
o UOM_DIST_VER_MNM
o VAL_LOWER_LIMIT
o TXT_RMK
based on
associated with
used as
specified for
TFC_FLOW_RTE_ELEMENT_LVL
* VAL_DIST_VER_LOWER
* UOM_DIST_VER_LOWER
* CODE_DIST_VER_LOWER
o VAL_DIST_VER_UPPER
o UOM_DIST_VER_UPPER
o CODE_DIST_VER_UPPER
DIRECT_FLIGHT
o TXT_RMK
end at
start at
DIRECT_FLIGHT_SEGMENT
used as
DIRECT_FLIGHT_CLASS
* VAL_EXCEED_LEN
* UOM_LEN